

modal ART

QUICKBUILD CONTAINERS

EBS .

Anti-Vandal Lock Installation



All the hardware is laid out including 5/16 or 8mm drill bit.



Marking the door for drilling. Notice the two arrows above the lock – when they align, the container is level.



Finishing the marking of the holes.



Drilling the holes



Fourth hole

modalART EBS – Anti-Vandal Lock Installation



Installing the hardware.



Back-plate is secured with washers and nuts.



Lock on the second door panel.

modalART EBS – Anti-Vandal Lock Installation



Second back-plate.

modalART EBS – Anti-Vandal Lock Installation



Finished job.

modalART EBS – Anti-Vandal Lock Installation

modalART

ModalART

Quick Build Containers

(203) 570 0150

info@modalart.com

www.modalart.com



WINNER
ISS 2015-2018
INSIDE SELF-STORAGE. **BEST OF BUSINESS**
MOST INNOVATIVE PRODUCT